

APPLICATION INSTRUCTIONS FOR
TRUCK CONSPICUITY SHEETING

Exceeds Standards

1. The conspicuity sheeting can be applied to flat surfaces. The surface must be free of rust, corrosion or loose paint. The sheeting can be applied at temperatures from 60°F to 100°F.
2. Before applying the sheeting, the surface must be free of dirt, grime and oils. It is best to assume that all surfaces are contaminated, and clean them before applying the sheeting.
 - Clean the surface with detergent
 - Rinse thoroughly and dry surface
 - Treat the surface with an alcohol wipe (isopropyl or methanol)
 - Make sure the surface is dry before application of the sheeting
3. Peel back about 6" of the release liner and align the sheeting so it is parallel with the trailer. Apply the sheeting by pressing along the face using a non-scratch application device (plastic squeegee with a low-friction sleeve or hand roller). Start at the edge of the sheeting and work towards the release liner to ensure air bubbles don't get trapped under the sheeting.

10 yards = 30 feet
25 yards = 75 feet
50 yards = 150 feet